



Tech Info Library

Super Serial Card: Cable for C.Itoh, C.Itoh F10 (11/96)

Revised: 11/21/96
Security: Everyone

Super Serial Card: Cable for C.Itoh, C.Itoh F10 (11/96)

Article Created: 04 December 1984
Article Reviewed/Updated: 21 November 1996

TOPIC -----

Listed below are the cable pinouts for connecting the Super Serial card to a C.Itoh or C.Itoh F10 printer.

DISCUSSION -----

C.Itoh Printer

Super Serial Card (SSC)	Pin	Cable	Pin	Printer Connector
Frame Ground	(FG)..... 1	<----->	1.....	(FG)
Transmit Data	(Tx) 2	<----->	3.....	(Rx)
Receive Data	(Rx) 3			
Request to send	(RTS) 4			
Clear To Send	(CTS) 5			
Data Set Ready	(DSR) 6	<----->	20.....	(DTR)
Signal Ground	(SG)..... 7	<----->	7.....	(SG)
Data Carrier Detect	(DCD) 8			
Secondary Clear To Send	(SCTS) ... 19			
Data Terminal Ready	(DTR) 20			

* Check C.Itoh owners manual for additional information on setting the printer's option jumpers.

C.Itoh F10 Printer

Super Serial Card (SSC)	Pin	Cable	Pin	Printer Connector
-------------------------	-----	-------	-----	-------------------

Frame Ground	(FG).....	1	<----->	1	(FG)
Transmit Data	(Tx)	2	<----->	3	(Rx)
Receive Data	(Rx)	3	<----->	2	(Tx)
Request to send	(RTS)	4	<----->	8	(DCD)
Clear To Send	(CTS)	5	<----->	8	(DCD)
Data Set Ready	(DSR)	6	<----->	20	(TDR)
Signal Ground	(SG).....	7	<----->	7	(SG)
Data Carrier Detect	(DCD)	8	<----->	4 & 5 ..	(RTS) & (CTS)
Secondary Clear To Send	(SCTS) ...	19			
Data Terminal Ready	(DTR)	20	<----->	6	(DSR)

* Use printer at 1200 Baud.

Article Change History:

21 Nov 1996 - Reviewed for technical accuracy, revised formatting.

Copyright 1984-96, Apple Computer, Inc.

Tech Info Library Article Number:929